



Features

- Universal input 90~305Vac (277Vac available)
- All-in-one function with Power supply, DC-UPS, battery charger and status monitoring in ONE compact unit
- Signal and alarms design meet UL2524,NFPA 1221,BS EN/EN54-4 requirement, with adjustable parameters configurable by communication interface
- Form C relay contacts and LED indicators for AC Fail, Battery Low, Charger Fail, and DC-OK
- Load-dependent high speed battery charging
- Built-in MODBus or CANBus protocol
- Protections: Short circuit / Overload / Over voltage / Over temperature(auto derating) / Battery reverse polarity (No damage) / Battery cut off
- Battery low protection / Battery reverse polarity protection
- -40 ~ +85°C wide operating temperature
- Cooling by free air convection
- Can be installed on DIN rail TS-35/7.5 or 15
- Charging curve can be set with SBP-001(only for CANBus model) (Smart programmer sold separately, please refer to: <https://www.meanwell.com/webapp/product/search.aspx?prod=SBP-001>)
- 20~100% charging current adjustable by VR
- 2 or 3-stage selectable by DIP S.W
- Suitable for lead acid and lithium-ion batteries
- Over voltage category III (OVC III)
- 3 years warranty

Description

DRS-960 is a 960W AC/DC DIN rail type security power supply series. In addition to the primary output, there is an additional charger circuit that will automatically adjust charge current depending on the primary output current. DRS-960 accepts the universal input between 90Vac and 305Vac, and supports output 24Vdc, 36Vdc, and 48Vdc nominal systems. With high efficiency up to 95.5%, it can operate with free air convection cooling under -40°C through +85°C ambient temperature. In addition to the key protection features such as overload protection, over voltage protection, battery low voltage disconnect, and battery reverse polarity protection, the DRS-960 also provides Form-C contacts and LED indicator alarm signals for AC-fail, battery low, charger fail, and DC-OK to allow easy integration into security systems that comply with local alarm codes.

Model Encoding

DRS - 960 - 48 MOD

Function option(Blank: Built-in MODBus, CAN: Built-in CANBus)

Output voltage(24V/36V/48V)

Rated wattage

Series name

Applications

- Public safety battery back-up (Red box)
- Security system
- Emergency lighting system
- Alarm system
- Uninterruptible DC-UPS system, battery detection system
- Central monitoring system
- Industrial automation

GTIN CODE


MW Search: <https://www.meanwell.com/serviceGTIN.aspx>

SPECIFICATION		DRS-960-24 ☐	DRS-960-36	DRS-960-48
		☐ =Blank, CAN		
OUTPUT				
OUTPUT VOLTAGE	Note.2	24V	36V	48V
LOAD CURRENT RANGE		0 ~ 40A	0 ~ 26.6A	0 ~ 20A
BATTERY CURRENT (CC)(max.)		30.8A	20.4A	15.4A
RECOMMENDED BATTERY CAPACITY(AMP HOURS)	Note.3	20 ~ 200AH	13 ~ 133AH	10 ~ 100AH
TOTAL OUTPUT POWER	Note.4	Combined power on all Channels must not exceed 960W, load has priority, 115% peak power capability within 5s		
RIPPLE & NOISE (max.)	Note.5	240mVp-p	360mVp-p	480mVp-p
VOLTAGE TOLERANCE	Note.6	± 1.0%	± 1.0%	± 1.0%
LINE REGULATION		± 0.5%	± 0.5%	± 0.5%
LOAD REGULATION		± 1.0%	± 1.0%	± 1.0%
SETUP, RISE TIME	Note.7	2400ms, 1000ms/230Vac 2400ms, 1000ms/115Vac at full load		
HOLD UP TIME (Typ.)		16ms/230Vac 10ms/115Vac at full load		
INPUT				
VOLTAGE RANGE		90 ~ 305Vac 127 ~ 431Vdc		
FREQUENCY RANGE		47 ~ 63Hz		
POWER FACTOR (Typ.)		PF>0.95/230Vac PF>0.98/115Vac at full load		
EFFICIENCY (Typ.)		94.5%	95%	95.5%
AC CURRENT (Typ.)		10.8A/115Vac 5.4A/230Vac		
INRUSH CURRENT (max.)		COLD START 30A/115Vac 60A/230Vac		
PROTECTION				
SHORT CIRCUIT (Power Mode)		Protection type: Constant current limiting, power will shutdown after 5 sec, re-power on to recover.		
OVERLOAD		105 ~ 135% rated output power		
		Protection type: Constant current limiting, shutdown output voltage after 5 sec.		
OVER TEMPERATURE		Automatically drop load with temperature only for bat. load. Protection type : Shut down o/p voltage, recover automatically after temperature goes down.		
OVER VOLTAGE		Load main output : 32.4 ~ 37.3Vdc	Load main output : 48.6 ~ 55.9Vdc	Load main output : 64.8 ~ 74.5Vdc
		Protection type : Shut down o/p voltage, re-power on to recover		
BATTERY CUT OFF		20.9±0.5Vdc	31.3±0.7Vdc	41.8±1Vdc
REVERSE POLARITY		By internal MOSFET, no damage, recovers automatically after fault condition is removed.		
FUNCTION				
FORM-C RELAY	AC FAIL	Signals AC failure and activates when input voltage drops below : 79~89Vac of 120Vac , 132~187Vac of 220Vac . Relay contact output, ON : AC OK ; OFF : AC Fail ; max. rating : 30Vdc/1A		
	CHARGER FAIL	Relay contact output, ON : Charger OK ; OFF : Charger Fail ; max. rating : 30Vdc/1A		
	DC OK	Signals normal DC output and activates when output voltage > 90% rated value. Relay contact output, ON : DC OK ; OFF : DC Fail ; max. rating : 30Vdc/1A		
	BATTERY LOW/ ABNORMAL/ DISCONNECTED	Relay contact output, ON : Battery OK ; OFF : Battery Low ; max. rating : 30Vdc/1A		
		Battery low voltage : < 22Vdc±0.3Vdc	Battery low voltage : < 33Vdc±0.4Vdc	Battery low voltage : < 44Vdc±0.5Vdc
BATTERY START		Restart system directly from battery and does not require AC power		
DC-UPS		UPS switch to battery power within 10ms of AC failure		
ADJUSTABLE CHARGING CURRENT		20% ~ 100% charging current adjustable by VR		
BATTERY TEMPERATURE COMPENSATION		The system can change the battery charging voltage by detecting the temperature (Please refer to page 9~10 for more details).		




ENVIRONMENT			
WORKING TEMP.		-40 ~ +85℃ (Refer to "Derating Curve")	
WORKING HUMIDITY		20% ~ 90% RH non-condensing	
STORAGE TEMP., HUMIDITY		-40 ~ +85℃, 10 ~ 95% RH non-condensing	
TEMP. COEFFICIENT		±0.03%/℃ (0 ~ 50℃) on Load output	
VIBRATION		10 ~ 500Hz, 5G 10min./1cycle, 60min. each along X, Y, Z axes	
OPERATING ALTITUDE		Note.8	2000 meters / OVC III ; 5000 meters / OVC II
OVER VOLTAGE CATEGORY		III; According to Dekra BS EN/EN62368-1; altitude up to 2000 meters	
SAFETY & EMC		Note.10	
SAFETY STANDARDS		UL62368-1, Dekra BS EN/EN62368-1, RCM AS/NZS 62368.1, EAC TP TC 004 approved	
WITHSTAND VOLTAGE		I/P-O/P: 4KVac I/P-FG: 2KVac O/P-FG: 1.5KVac	
ISOLATION RESISTANCE		I/P-O/P, I/P-FG, O/P-FG: 100M Ohms/500Vdc/25℃ / 70%RH	
EMC EMISSION	Parameter	Standard	Test Level / Note
	Conducted	BS EN/EN55032(CISPR32)	Class B
	Radiated	BS EN/EN55032(CISPR32)	Class A ;Class B(With external 13*26*30 NIZN magnetic clasp)
	Harmonic current	BS EN/EN61000-3-2	-----
	Voltage flicker	BS EN/EN61000-3-3	-----
EMC IMMUNITY	BS EN/EN55035 , BS EN/EN61204-3, BS EN/EN61000-6-2(BS EN/EN50082-2)		
	Parameter	Standard	Test Level /Note
	ESD	BS EN/EN61000-4-2	Level 3, 8KV air ; Level 2, 6KV contact; criteria A
	Radiated	BS EN/EN61000-4-3	Level 3, 10V/m ; criteria A
	EFT bursts	BS EN/EN61000-4-4	Level 3, 2KV ; criteria A
	Surge	BS EN/EN61000-4-5	Level 3, 1KV/Line-Line ;Level 3, 2KV/Line-Line-Chassis ;criteria A
	Conducted	BS EN/EN61000-4-6	Level 3, 10V ; criteria A
	Magnetic field	BS EN/EN61000-4-8	Level 4, 30A/m ; criteria A
FIRE DETECTION AND FIRE ALARM SYSTEM	Compliance to BS EN/EN54-4		
OTHERS			
MTBF		K hrs min. Telcordia SR-332 (Bellcore) ; K hrs min. MIL-HDBK-217F (25℃)	
DIMENSION (L*W*H)		110*125.2*150.7mm	
PACKING		Kg; pcs/Kg/CUFT	
NOTE			
1. All parameters NOT specially mentioned are measured at 230Vac input, rated load and 25℃ of ambient temperature. 2. Variable with charger voltage when battery is connected. 3. This is Mean Well's suggested range. Please consult your battery manufacturer for their suggestions about maximum charging current limitation. 4. If load current increases, the system will prioritize load current demand and automatically reduce the battery charging current. 5. Ripple & noise are measured at 20MHz of bandwidth by using a 12" twisted pair-wire terminated with a 0.1 μ F & 47 μ F parallel capacitor. 6. Tolerance : includes set up tolerance, line regulation and load regulation. 7. Length of setup time is measured at cold first start, Turning ON/OFF the power supply may lead to increase of the setup time. 8. The ambient temperature derating of 3.5℃/1000m with fanless models and of 5℃/1000m with fan models for operating altitude higher than 2000m(6500ft). 9. Installation clearances : 40mm on top, 20mm on the bottom, 5mm on the left and right side are recommended when loaded permanently with full power. In case the adjacent device is a heat source, 15cm clearance is recommended. 10. The power supply is considered a component which will be installed into a final equipment. The final equipment must be re-confirmed that it still meets EMC directives.For guidance on how to perform these EMC tests, please refer to "EMI testing of component power supplies." (as available on https://www.meanwell.com/Upload/PDF/EMI_statement_en.pdf) ※ Product Liability Disclaimer : For detailed information, please refer to https://www.meanwell.com/serviceDisclaimer.aspx			


Block Diagram



Derating Curve



Static Characteristics



Function manual

1. Alarm signals

- (1) Alarm Signal is sent out through "AC fail " & " Battery low " & " Charger fail " pins via relay contact.
- (2) An external voltage source is required for this function. The maximum applied voltage is 30Vdc and the maximum sink current is 1A. Please refer to Fig 1.2.
- (3) Table 1.1 explains the alarm function built in the power supply

INPUT	AC fail		DC OK		Battery low/Abnormal /Disconnected		Charger fail	
	2-3	1-3	5-6	4-6	8-9	7-9	11-12	10-12
AC only	closed	open	closed	open	open	closed	-----	-----
AC + BAT.	closed	open	closed	open	closed	open	-----	-----
BAT. only	open	closed	closed	open	closed	open	-----	-----
Low BAT. (<30% capacity)	-----	-----	-----	-----	open	closed	-----	-----
Charger Fail	-----	-----	-----	-----	-----	-----	open	closed

Table 1.1 Explanation of alarm signal




Fig 1.1 alarm signal Terminals

AC fail (Battery low)





Fig 1.2 Internal circuit of AC fail (Battery low), via relay contact

2.DC-UPS function

When AC mains drops below:79~89Vac of 120Vac,132~187Vac of 220Vac, UPS function will activate and power source switch battery backup.




3.Charger setting

3.1.1 2 or 3-stage selectable by DIP S.W


※ This series provides 2 or 3 stage charging curve.

1	OFF: 3 stage(Default), ON: 2 stage
2	Charging curve adjustable:see below
3	



3.1.2 Charging curve can be adjustable by DIP S.W


◎ 2 stage charging curve



State	DRS-960-24 □	DRS-960-36 □	DRS-960-48 □
Constant Current	30.8A(200-277Vac) 24.6A(100-200Vac)	20.4A(200-277Vac) 16.3A(100-200Vac)	15.4A(200-277Vac) 12.3A(100-200Vac)
Vboost	28.8Vdc	43.2Vdc	57.6Vdc

◎ Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

◎ Default 3 stage charging curve



State	DRS-960-24 □	DRS-960-36 □	DRS-960-48 □
Constant Current	30.8A(200-277Vac) 24.6A(100-200Vac)	20.4A(200-277Vac) 16.3A(100-200Vac)	15.4A(200-277Vac) 12.3A(100-200Vac)
Vboost	28.8Vdc	43.2Vdc	57.6Vdc
Vfloat	27.6Vdc	41.4Vdc	55.2Vdc

◎ Suitable for lead-acid batteries (flooded, Gel and AGM) and Li-ion batteries (lithium iron and lithium manganese).

※ The default curve is programmable, whereas other pre-defined curves can be activated by the means of the DIP S.W; please refer to the table below and the Mechanical Specification.

◎ Embedded **2 stage** charging curve

DIP SW position		24V model		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	30.8A (200-277Vac)	28.8Vdc
ON	OFF	Pre-defined, gel batter		28Vdc
OFF	ON	Pre-defined, flooded battery	24.6A (100-200Vac)	28.4Vdc
ON	ON	Pre-defined, AGM battery, LiFe04		29.2Vdc
DIP SW position		36V model		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	20.4A (200-277Vac)	43.2Vdc
ON	OFF	Pre-defined, gel battery		42Vdc
OFF	ON	Pre-defined, flooded battery	16.3A (100-200Vac)	42.6Vdc
ON	ON	Pre-defined, AGM battery, LiFe04		43.8Vdc
DIP SW position		48V model		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	15.4A (200-277Vac)	57.6Vdc
ON	OFF	Pre-defined, gel battery		56Vdc
OFF	ON	Pre-defined, flooded battery	12.3A (100-200Vac)	56.8Vdc
ON	ON	Pre-defined, AGM battery, LiFe04		58.4Vdc

◎ Embedded **3 stage** charging curve

DIP SW position		24V model			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	30.8A (200-277Vac)	28.8Vdc	27.6Vdc
ON	OFF	Pre-defined, gel batter		28Vdc	27.2Vdc
OFF	ON	Pre-defined, flooded battery	24.6A (100-200Vac)	28.4Vdc	26.8Vdc
ON	ON	Pre-defined, AGM battery, LiFe04		29.2Vdc	28Vdc
DIP SW position		36V model			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	20.4A (200-277Vac)	43.2Vdc	41.4Vdc
ON	OFF	Pre-defined, gel battery		42Vdc	40.8Vdc
OFF	ON	Pre-defined, flooded battery	16.3A (100-200Vac)	42.6Vdc	40.2Vdc
ON	ON	Pre-defined, AGM battery, LiFe04		43.8Vdc	42Vdc
DIP SW position		48V model			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	15.4A (200-277Vac)	57.6Vdc	55.2Vdc
ON	OFF	Pre-defined, gel battery		56Vdc	54.4Vdc
OFF	ON	Pre-defined, flooded battery	12.3A (100-200Vac)	56.8Vdc	53.6Vdc
ON	ON	Pre-defined, AGM battery, LiFe04		58.4Vdc	56Vdc

3.2 SBP-001 can adjust the charging curves (Only CANBus Model)

◎ **2 stage** charging curve (programmable)

DIP SW position		24V model		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	30.8A(200-277Vac) 24.6A(100-200Vac)	28.8Vdc
DIP SW position		36V model		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	20.4A(200-277Vac) 16.3A(100-200Vac)	43.2Vdc
DIP SW position		48V model		
2	3	Description	CC(default)	Vboost
OFF	OFF	Default, programmable	15.4A(200-277Vac) 12.3A(100-200Vac)	57.6Vdc

◎ **3 stage** charging curve (programmable)

DIP SW position		24V model			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	30.8A(200-277Vac) 24.6A(100-200Vac)	28.8Vdc	27.6Vdc
DIP SW position		36V model			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	20.4A(200-277Vac) 16.3A(100-200Vac)	43.2Vdc	41.4Vdc
DIP SW position		48V model			
2	3	Description	CC(default)	Vboost	Vfloat
OFF	OFF	Default, programmable	15.4A(200-277Vac) 12.3A(100-200Vac)	57.6Vdc	55.2Vdc

※ SBP-001 is a programmer, particularly for MEAN WELL's various programmable battery charger models to program the parameters of charging curves, such as the Constant current (CC), tapper current (TC), Constant voltage (CV), float voltage (FV) and so on, to accommodate the diversified battery specification in industry. With the design accounting for simplicity and convenience, users can easily configure MEAN WELL's programmable battery chargers with SBP-001 programmer and the computer; all of the setups are able to be finished easily by the means of the specific software.


Note: (1) Tapper current (TC) default is 10%, can be fine tuned from 2% to 30% by SBP-001 with computer or CANBus Interface.

(2) The SBP-001 only supports CANBus version (DRS-960-xxCAN).

(3) Please contact MEAN WELL for more details.



※ Communication cable for DRS series



DRS series pin assignment :

Connector	Pin Assignment									
SBP-001 10pin connector (Connector part No.:HRS DF11-10DS)	1	2	3	4	5 (CANH)	6 (CANL)	7	8	9	10 (GND)
DRS-960 RJ45 Communication port	----	----	----	----	6	7	----	----	----	8
Wire color	----	----	----	----	Green	White/Brown	----	----	----	Brown


3.3 Communication interface

Charging parameters can be modified by MODBus (DRS-960-xx) or CANBus(DRS-960-xxCAN) communication commands.
For details, please refer to: <http://www.meanwell.com/manual.html>


4.Power Boost Mode

The maximum current on the load output is the 2 times the rated current for 4 minutes max. and 3 times the rated current for 4 seconds max.
For example (48V model@200-277Vac):

Output load



5. Battery temperature compensation



- ◎ To exploit the temperature compensation function, please attach the temperature sensor(NTC) which is enclosed with DRS-960, to the battery or the battery's vicinity.
- ◎ DRS-960 is able to work normally without the temperature sensor(NTC).

- 5.1 The compensation parameters included Disable, -3, -4 and -5mV/ °C /Cell .It can be modified by communication command of CANBus, MODBus. The factory default value is -3mV/ °C /Cell.
- 5.2 It will be regarded as normal temperature and will not be compensated when temperature compensation resistance is not connected; And temperature compensation will only compensate lead-acid battery, not lithium iron battery.
- 5.3 The range of temperature compensation is 0-40°C , normal temperature 25°C is the central value, no compensation; When the temperature is < 0 °C or > 40 °C , the current temperature compensation value will be limited to 0 °C or 40°C.

24V model as an example

Assuming that $V_{boost}=28.8V$, temperature compensation set to -5mV/°C/Cell by communication, TEMP_bat is NTC temperature detection.

The compensating voltage can be calculated by the following equation:

$$V_{boost_comp}=28.8V-5mV*(TEMP_bat-25^{\circ}C)*12Cell$$

Max. compensation voltage:



$$V_{boost_H}=28.8V-5mV*(0^{\circ}C-25^{\circ}C)*12Cell=30.3V$$


Min. compensation voltage:

$$V_{boost_L}=28.8V-5mV*(40^{\circ}C-25^{\circ}C)*12Cell=27.9V$$

5.4 Accessory List

※ NTC Sensor and mating wire along with DRS-960 (Standard accessory)

Item		Quantity
1	NTC sensor wire Part No.: NSG05C250J5 	1
2	Mating wire  JS-2007-2*4-T or equivalent	1



6.LED alarm

Function		Description	Output of alarm
DC OK		DC fail	OFF 
		DC OK	Green 
AC fail		AC fail	Red 
		AC OK	OFF 
Status	Charging status	Float	Green 
		Charging: CC/CV	Orange 
	System diagnosis	Discharging	Orange: 1 Blink/Pause  
		Charger fail	Red : 1 Blink/Pause  
		Battery overvoltage / Battery reverse polarity	Red : 2 Blink/Pause  
		Battery low / No Battery	Red : 3 Blink/Pause  
		Battery discharge peak power timeout.	Red : 4 Blink/Pause  
		Over load / short	Red : 5 Blink/Pause  
		Over temperature	Red : 6 Blink/Pause  
		Timeout	Red : 7 Blink/Pause  

Suggested Application

1.Backup connection for AC interruption

(1) Please refer to Fig2.1 for suggested connection.

The power supply charges the battery and provides energy to the load at the same time when AC mains is OK.
The battery starts to supply power to the load when AC mains fails.




Fig 2.1 Suggested system connection

(2) Backup time

Backup time depends on:

- ✖ from the load current
- ✖ from the size of the batteries.

The following table is an example (battery capacity at C10 discharge rate).

Battery Load	10AH	20AH	50AH	100AH	200AH
1.5A	350min	13h	33h	67h	133h
3A	125min	350min	17h	33h	67h
5A	60min	180min	600min	20h	40h
7.5A	35min	90min	350min	13h	27h
10A	23min	60min	240min	10h	20h
15A	13min	35min	125min	350min	13h


Mechanical Specification

(Unit: mm , tolerance ± 1 mm)

Case No. 214C

Terminal Pin No. Assignment (TB3)

Pin No.	Assignment
1,2	DC Output +Vo
3,4	DC Output -Vo



Terminal Pin No. Assignment (TB2)


Pin No.	Assignment
1,2	BAT.-
3,4	BAT. +

Force button Connector (CN12):
JS-2008R-4*2-T or equivalent

Pin No.	Assignment
1	3.3V
2	GND
3	RTH+
4	RTH-
5	A0
6	A1
7,8	Open: Normal Short: Force start


Terminal Pin No. Assignment (RJ45)

Pin No.	Function	Description
1,2,3,4,5	NC	Retain for future use.
6	D-/DB	For MODBus model:Serial Date used in the MODBus interface.
	CANH	For CANBus model:Date line used in the CANBus interface.
7	D+/DA	For MODBus model:Serial Clock used in the MODBus interface.
	CANL	For CANBus model:Date line used in the CANBus interface.
8	GND-AUX	Auxillary voltage output GND. The signal return is isolated from the output terminals(+V & -V).




Terminal Pin No. Assignment (TB4)

Pin No.	Assignment
1,2,3	AC fail
4,5,6	DC OK
7,8,9	Battery low/ Abnormal/ Disconnected
10,11,12	Charger fail



Terminal Pin No. Assignment (TB1)


Pin No.	Assignment
1	FG ⊕
2	AC/N or DC Input +Vo
3	AC/L or DC Input -Vo



■ Recommend Wiring

	AC Input T.B	DC Output T.B
Solid Wire	6mm ² max.	6mm ² max.
A.W.G	18~10 AWG	16~10 AWG

■ Installation Instruction



This series fits DIN rail TS35/7.5 or TS35/15.
For installation details, please refer to the Instruction manual.

ADMISSIBLE DIN rail: TS35/7.5 OR TS35/15
(For reference only. Not included with unit.)

■ Installation Manual

Please refer to : <http://www.meanwell.com/manual.html>